

VALLEYCARE
OLIVE VIEW-UCLA MEDICAL CENTER/HEALTH CENTERS
DEPARTMENT: FACILITIES
POLICY & PROCEDURE

NUMBER: 519
VERSION: 1

SUBJECT/TITLE: CADAVER CASE / REFRIGERATOR

POLICY: Check temperature monthly.

PROCEDURE: Observe temperature in case and record in monthly log. Temperature should be 34° to 40° F.

POLICY: Clean condenser every four (4) months.

PROCEDURE: Using compressed air, blow through condenser coil in reverse direction on airflow.

EMERGENCY PROCEDURE: Install backup unit kept on hand by Facilities Division.

PURPOSE:

DEPARTMENTS: FACILITIES

DEFINITIONS:

References:	
Approved by: Robert Ross (Director, Facilities)	Date: 08/12/2009
Review Date: 07/12/2015	Revision Date:
Distribution: Facilities	
Original Date: 08/12/2009	