VALLEYCARE OLIVE VIEW-UCLA MEDICAL CENTER/HEALTH CENTERS DEPARTMENT: FACILITIES POLICY & PROCEDURE

NUMBER: 513 VERSION: 1

SUBJECT/TITLE: INFECTION CONTROL POLICY

POLICY:

The A/C and Steam Shop will perform scheduled and unscheduled maintenance on air conditioning systems and other equipment to help prevent the growth of infections agents in these systems/equipment. This work shall be performed in a manner that will protect the health of employees and patients.

PROCEDURE: REFRIGERATORS: Checked for operation and cleanliness once a year and so

logged by our personnel. P.M. log is kept in facilities.

STERILIZERS: Maintenance and monthly P.M. logged in book in P.C.S.

surgery autoclave is checked monthly and so logged by our division. Space tests are run by P.C.S. personnel. Sterilizers

are cleaned and logged by both divisions.

A/C UNITS: Filters are changed in accord with the Preventive Maintenance

Program and logged by mechanical personnel. 95% filters are changed annually or when static is above 1.5 over clean rating. A/C units are treated continuously with tablets to

prevent the growth of bacteria when applicable.

COOLING TOWERS: Cooling towers are cleaned, chemically treated, and the

water is tested in accord with the frequencies defined in the

Preventive Maintenance Program.

ICE MACHINES: Ice Machines are cleaned and checked monthly. We check

quality of makeup water and operation of unit. Employees are

instructed on cleanliness to insure product quality.

EMPLOYEE SAFETY: The risk to employees changing filters is moderate;

therefore, they are to wear gloves, mask, goggles, and

coveralls while handling dirty filters.

PATIENT SAFETY: Prior to working on A/C systems, workers shall take

precautions to prevent dust and dirt from contaminating the

system.

SUBJECT/TITLE: INFECTION CONTROL POLICY

Policy Number: 513
Page Number: 2

PURPOSE:

DEPARTMENTS: FACILITIES

DEFINITIONS:

| References: | |
|-------------------------------------------------|------------------|
| Approved by: Robert Ross (Director, Facilities) | Date: 08/12/2009 |
| Review Date: 07/12/2015 | Revision Date: |
| Distribution: Facilities | |
| Original Date: 08/12/2009 | |