

VALLEYCARE
OLIVE VIEW-UCLA MEDICAL CENTER/HEALTH CENTERS
DEPARTMENT: FACILITIES
POLICY & PROCEDURE

NUMBER: 530
VERSION: 1

SUBJECT/TITLE: EVAPORATIVE COOLERS

POLICY: Clean, inspect, oil, and change pads annually.

PROCEDURE: Turn off unit. Remove old pads and replace with new oil bearings. Check belt and pump for operation. Check pan for leaks. Check float valve for operation. Reassemble and start. Check for proper operation.

PURPOSE:

DEPARTMENTS: FACILITIES

DEFINITIONS:

References:	
Approved by: Robert Ross (Director, Facilities)	Date: 08/12/2009
Review Date: 07/12/2015	Revision Date:
Distribution: Facilities	
Original Date: 08/12/2009	