

**VALLEYCARE**  
**OLIVE VIEW-UCLA MEDICAL CENTER/HEALTH CENTERS**  
**DEPARTMENT: FACILITIES**  
**POLICY & PROCEDURE**

**NUMBER: 608**  
**VERSION: 1**

**SUBJECT/TITLE:** SURGERY, ICU, AND RECOVERY LINE ISOLATION MONITORS

**POLICY:** Line isolation monitors will be checked monthly and calibrated semi-annually.

**PURPOSE:**

**PROCEDURE:** Line isolation monitors will be checked monthly by the test switch. The line isolating monitor will be calibrated at periods no to exceed semi-annual with the testing resistor by faulting one side of the line to ground. Fault currents or excessive leakage cannot exceed 5 milliamps.

**DEPARTMENTS:** FACILITIES

**DEFINITIONS:**

|   |                  |
|---|------------------|
| References:                                     |                  |
| Approved by: Robert Ross (Director, Facilities) | Date: 08/12/2009 |
| Review Date: <b>07/12/2015</b>                  | Revision Date:   |
| Distribution: Facilities                        |                  |
| Original Date: 08/12/2009                       |                  |