

**VALLEYCARE**  
**OLIVE VIEW-UCLA MEDICAL CENTER/HEALTH CENTERS**  
**DEPARTMENT: FACILITIES**  
**POLICY & PROCEDURE**

**NUMBER: 639**  
**VERSION: 1**

**SUBJECT/TITLE: DARK ROOM EQUIPMENT**

**POLICY:** Plumbers monitor dark room equipment to ensure equipment is in proper working condition.

**PURPOSE:**

**DEPARTMENTS: FACILITIES**

**DEFINITIONS:**

**PROCEDURE:** Plumbers inspect X-O Mat equipment every six (6) months, checking for leaks and checking temperature reading on temp flow unit. Drains are also checked to ensure against stoppages. Omni-pure filters are changed monthly. Back flow devices are certified every year by a licensed back flow tester.

References:	
Approved by: Robert Ross (Director, Facilities)	Date: 08/12/2009
Review Date: <b>07/12/2015</b>	Revision Date:
Distribution: Facilities	
Original Date: 08/12/2009	